

## CIRCULATOR REPLACEMENT GUIDE (SERIES UP)

### CLOSED SYSTEMS (Cast Iron Construction)

| GRUNDFOS                               | TACO                         | BELL & GOSSETT                | ARMSTRONG                | LAING    |
|--|------------------------------|-------------------------------|--------------------------|----------|
| UP15-42F/FR<br>(BRUTE II)<br>UPS15-42F | 005, 007, 008                | LR20-BF<br>NRF-22,<br>100 NFI | S25, SS-30*<br>ASTRO 30  | SM909-14 |
| UP26-64F                               | 009, 0010, 110,<br>113, 0014 | PR                            | SF15*, SS-50<br>S25, S35 | SM909-23 |
| UP26-96F<br>UP26-99F                   | 009, 0011, 113<br>0013       | PR, PL36<br>PR B1             | H41                      | N/A      |
| UP26-116F                              | NA                           | PL36                          | N/A                      | N/A      |
| UP43-75F                               | 111, 112, 0012, 0014         | HV, Ser. 1-1/2", PL45         | S34, H32, H41            | N/A      |
| UP50-75F●                              | 0012 F2                      | 2"                            | S35                      | N/A      |

### OPEN SYSTEMS (Stainless Steel or Bronze Construction)

|   |   |                                       |                                       |                  |
|---|---|---------------------------------------|---------------------------------------|------------------|
| UP15-10B5◆<br>UP15-10B7◆<br>UP15-18SU▲<br>UP15-18SF<br>UP15-18B5◆<br>UP15-18B7◆ | 006B  | NBF 12/22<br>NBF 12/22U               | ST10B*, SF15B*<br>ASTRO 30B           | SM202B<br>SM303B |
| UP15-42SU▲<br>UP15-42SF<br>UP15-42B5◆   | 005B, 007B  | NBF 12/22<br>LR15-B<br><br>Ser. 100-B | ST10B, SF15B,<br>SS-30B*              | SM909-14B        |
| UP25-64SU▲<br>UP25-64SF<br>UP15-42B7◆   | 008B, 110B  | LR12-B, LR15-B,<br>Ser. 100-B,        | SR15B*, S25B,<br>SS-50B*,<br>ASTRO 50 | SM909-23B        |
| UP26-96BF<br>UP26-99BF  | 009B, 0010B,<br>0011B, 110B,<br>113B, 0013, 0013B | PR-B, LR12-B                          | H41B,<br>SS-100B*                     | N/A              |
| UP26-116BF  | NA  | PL36B                                 | N/A                                   | N/A              |
| UP43-75BF   | 111B, 112B,<br>0012B, 0014B                       | PL45B, HVB,<br>Ser. 1 1/2" B          | S34B*, H32B,<br>H41B                  | N/A              |